



## Instructions for Connecting Smart Home Devices with OHD Anywhere®


---

### Google Assistant Instructions

- Download the Google Home App and the Google Assistant App
  - You will need your Gmail account (or need to create one)
- Log in to the Google Home and Google Assistant Apps
- Configure the Wi-Fi of your Google Home device as directed in the Google Home App
- Set up the Google Assistant on the Google Home App as directed
- Go to the Profile tab >> More Settings >> Assistant >> Voice Match >>and set up the voice match feature
- Go to the Profile tab >> More Settings >> Assistant >> Assistant Devices >> Name of Your Device >> Enable Personal Results
- You should now be logged in to the Google Home App and Google Assistant with the same User ID


## Instructions for Connecting Smart Home Devices with OHD Anywhere®

1. Log into the Google Assistant App with the same user ID as in Google Home and you will see the following screen. Search for “OHD Anywhere®” in the text box shown.




## Instructions for Connecting Smart Home Devices with OHD Anywhere®

2. You will be navigated to the following screens to link your accounts together. Click "LINK".



## Instructions for Connecting Smart Home Devices with OHD Anywhere®


3. Enter your OHD Anywhere® App login credentials here to link your OHD Anywhere® App account to your Google account.



The screenshot shows a mobile browser interface for linking an account. At the top, the status bar shows 'Safari', signal strength, Wi-Fi, time '11:47 PM', and battery '75%'. The browser title is 'Link Account'. The address bar shows 'Done', a lock icon, 'app.apps.st1.gdocntl.net', and a refresh icon. Below the address bar is the OHD ANYWHERE logo. The main content area contains the following text: 'This app would like the ability to access your OHD Anywhere account. Use the email and password from your existing OHD Anywhere account to sign in below. You will need to create a PIN number to complete the sign in process.' Below this text are three input fields: 'Email' with a green underline, 'Password' with the placeholder 'Enter password' and a grey underline, and 'PIN' with the placeholder 'Enter 4 digit access PIN' and a grey underline. At the bottom of the browser, there are navigation icons: back, forward, share, and search.

## Instructions for Connecting Smart Home Devices with OHD Anywhere®

4. Enter your OHD Anywhere® App login credentials here to link your OHD Anywhere® App account to your Google Home account.
  - Enter a PIN and click “Login”
    - You will be able to remove this PIN later if you choose, however, by disabling your PIN, understand that you are deactivating a feature meant to provide an additional level of security.



T-Mobile Wi-Fi 11:41 PM 78%

< Link Account X

app.apps.st1.gdocntl.net

This app would like the ability to access your Aladdin Connect account. Use the email and password from your existing Aladdin Connect account to sign in below. You will need to create a PIN number to complete the sign in process.

Email  
EmailUsedWithOHDAnywhere@example.com

Password  
●●●●●●


PIN  
1234

\*You can disable the PIN feature later if you prefer.

Login


## Instructions for Connecting Smart Home Devices with OHD Anywhere®

5. After login you will see the following screen. Click 'TRY IT'.
  - At this time, your OHD Anywhere® account is linked to your Google account. There are instructions on the skill screen as to how to talk to OHD Anywhere®. For example, “Hey Google, Start OHD Anywhere”, “Hey Google, Open OHD Anywhere”.
  - Going forward, you can ask questions from OHD Anywhere®.



## Instructions for Connecting Smart Home Devices with OHD Anywhere®

- When you click “TRY IT”, you are navigated to the following screen and OHD Anywhere® starts talking.





## Instructions for Connecting Smart Home Devices with OHD Anywhere®

---

### AVAILABLE VOICE COMMANDS

#### “Hey Google - Ask OHD Anywhere to”

- Open my door
- Open (Door Name)
- Close my door
- Close (Door Name)
- Open All of my doors
- Close All of my doors
- List my doors
- Disable/Enable my PIN

#### “Hey Google – Ask OHD Anywhere if”

- My door is open?
- My door is closed?
- My door is open or closed?
- (Door Name) is open?
- (Door Name) is closed?
- (Door Name) is open or closed?

- Click [HERE](#) or search “Google Home Help” at Google.com



## Instructions for Connecting Smart Home Devices with OHD Anywhere®

### Amazon Alexa Instructions

- Download Amazon Alexa App
- Click: “Menu” (in upper left corner)
- Click: “Skills and Games”
- Click: “Search”, and type “OHD Anywhere® “
- Click: “Enable to use”
- You will see a log in page
  - Enter email address and password for OHD Anywhere®
  - Create a new PIN (can be disabled later)
- OHD Anywhere has been set up
- Disabling your PIN using voice commands:  
“Alexa: tell OHD Anywhere® to disable my PIN”
  - By disabling your pin, you are deactivating a feature meant to provide and additional level of security
  - Follow prompts:
    - "Please say your PIN to proceed" - Say your PIN
    - PIN has been disabled
- Your OHD Anywhere® account has been successfully set up.
- Find the voice commands listing below.

### AVAILABLE VOICE COMMANDS

#### “Alexa - Ask OHD Anywhere® to”

- Open my door
- Open (Door Name)
- Close my door
- Close (Door Name)
- Open All of my doors
- Close All of my doors
- List my doors
- Disable/Enable my PIN

#### “Alexa – Ask OHD Anywhere® “if”

- My door is open?
- My door is closed?
- My door is open or closed?
- (Door Name) is open?
- (Door Name) is closed?
- (Door Name) is open or closed?

Additional Information can be found here for [Amazon Alexa](#).